

Cross-Cut Saw

- Read or be familiar with tool operation. See general instructions posted near the machine
- If you need assistance with any operation, please ask the shop monitor or shop manager for help
- Crosscutting only. No miter cuts (use sliding compound miter saw)
- Do not cut round or oval wood. Cut them on band saw
- For a smoother cut, cut with the good side facing down
- Before starting a cut, make sure the motor is at full operation speed
- Cut slowly. Give the saw time to cut
- Push the saw back as well as pulling through to eliminate stalling. Do not let saw retract back by itself
- Do not cross arms when holding wood against the fence. If wood is on the left side of blade, hold wood with left hand and pull with right hand
- Keep top free of unnecessary items (tape, extra wood)
- Place straightedge of board against fence when possible. If not possible, put convex (bow or outward curve side) not concave side against the fence to prevent pinching of blade
- To avoid kickback, always hold the work piece securely against the table and fence
- You can cross cut up to 23 ½”(24” if you raise the end)
- If you raise the blade, lower it back to just below the table top
- Clean up when finished

