

Panel Saw

The Panel Saw is for cutting large sheet goods such as plywood. Place the piece securely in the slot at the bottom. Start the saw and pull it downward on its rails. It helps to have another person steady large pieces during the cut. The blade can be rotated 90 degrees to make horizontal cuts. Rotate and lock on the rails at the desired height. The material is then pushed through the saw. Use the spacers (hanging on strings) to keep the blade from being pinched. Be sure that the top piece is held securely so as not to drop down and pinch the blade while cutting or to fall at the end of the cut.